

CINTA BROTHER TZE-S631, TZES631 NEGRO SOBRE AMARILLO

ESPECIFICACIONES
CARACTERISTICAS PRINCIPALES

| | |
|---------------------------|--------------------------|
| Fabricante | Industrias Brother, LTD. |
| Marca | Brother |
| Modelo | S631 |
| SKU | TZE-S631 |
| MPN | TZE-S631 |
| Serie | STZE-S631 |
| Color | Negro sobre Yellow |
| Presentación del Producto | Original |
| Material | Cartucho de Cinta |
| País de Origen | Japón |
| País de Procesamiento | Japón |
| País de Ensamblaje | Japón |
| Fecha de Lanzamiento | 2021-10-09 |
| Fecha de Producción | 2021-10-09 |

DIMENSIONES Y PESO

| | |
|-------------|-------|
| Ancho | 8 cm |
| Altura | 15 cm |
| Profundidad | 2 cm |
| Peso | 10 gr |

EMPAQUETADO

| | |
|----------------------|-------------------|
| Tipo de embalaje | Caja |
| Cantidad por paquete | 1 |
| Contenido de la caja | Cartucho de Cinta |

RENDIMIENTO

| | |
|--------|--------------------------|
| Tamaño | 12mm x 8.00 de impresion |
|--------|--------------------------|

USAR EN IMPRESORAS

| | | |
|---|---|--|
|  Brother PT-1280SR |  Brother PT-1280VP |  Brother PT-128AF |
|  Brother PT-1290 |  Brother PT-1290BT |  Brother PT-1290BT2 |
|  Brother PT-1290RS |  Brother PT-1300 |  Brother PT-1400 |
|  Brother PT-1500 |  Brother PT-1500PC |  Brother PT-1600 |
|  Brother PT-1700 |  Brother PT-1750 |  Brother PT-1800 |
|  Brother PT-1810 |  Brother PT-1830 |  Brother PT-1830C |

| | | |
|---|---|--|
|  Brother PT-1830SC |  Brother PT-1830VP |  Brother PT-1880C |
|  Brother PT-1880SC |  Brother PT-1880W |  Brother PT-1890C |
|  Brother PT-1890SC |  Brother PT-1890W |  Brother PT-18R |
|  Brother PT-18RKT |  Brother PT-1900 |  Brother PT-1910 |
|  Brother PT-1950 |  Brother PT-1960 |  Brother PT-200 |
|  Brother PT-2030 |  Brother PT-2030AD |  Brother PT-2030VP |
|  Brother PT-2100 |  Brother PT-2110 |  Brother PT-2200 |
|  Brother PT-2210 |  Brother PT-2300 |  Brother PT-2310 |
|  Brother PT-2400 |  Brother PT-2410 |  Brother PT-2430PC |
|  Brother PT-2500PC |  Brother PT-2600 |  Brother PT-2610 |
|  Brother PT-2700 |  Brother PT-2710 |  Brother PT-2730 |
|  Brother PT-2730VP |  Brother PT-300 |  Brother PT-300B |
|  Brother PT-310 |  Brother PT-310B |  Brother PT-320 |
|  Brother PT-330 |  Brother PT-340 |  Brother PT-350 |
|  Brother PT-3600 |  Brother PT-4000 |  Brother PT-520 |
|  Brother PT-530 |  Brother PT-540 |  Brother PT-550 |
|  Brother PT-580C |  Brother PT-6100 |  Brother PT-7100 |
|  Brother PT-7500 |  Brother PT-7600 |  Brother PT-9200DX |
|  Brother PT-9200PC |  Brother PT-9400 |  Brother PT-9500PC |
|  Brother PT-9600 |  Brother PT-9700PC |  Brother PT-9800PCN |
|  Brother PT-D200 |  Brother PT-D200BT |  Brother PT-D200DA |
|  Brother PT-D200G |  Brother PT-D200MA |  Brother PT-D200SA |

| | | |
|---|---|---|
|  Brother PT-D210 |  Brother PT-D400 |  Brother PT-D400AD |
|  Brother PT-D400VP |  Brother PT-D450 |  Brother PT-D600 |
|  Brother PT-D600VP |  Brother PT-D800W |  Brother PT-E100 |
|  Brother PT-E105 |  Brother PT-E110 |  Brother PT-E300 |
|  Brother PT-E500 |  Brother PT-E550W |  Brother PT-E800W |
|  Brother PT-H100 |  Brother PT-H110 |  Brother PT-H300 |
|  Brother PT-H300LI |  Brother PT-H500LI |  Brother PT-P700 |
|  Brother PT-P750W |  Brother PT-P750WVP |  Brother PT-P900 |
|  Brother PT-P900W |  Brother PT-P950NW |  Brother GL-100 |
|  Brother PT-1000 |  Brother PT-1000BM |  Brother PT-1010 |
|  Brother PT-1010B |  Brother PT-1010NB |  Brother PT-1010R |
|  Brother PT-1010S |  Brother PT-1090 |  Brother PT-1090BK |
|  Brother PT-1100 |  Brother PT1100SB |  Brother PT-1100SBVP |
|  Brother PT-1100ST |  Brother PT-1120 |  Brother PT-1130 |
|  Brother PT-1160 |  Brother PT-1170 |  Brother PT-1180 |
|  Brother PT-1190 |  Brother PT-11Q |  Brother PT-1200 |
|  Brother PT-1230PC |  Brother PT-1280 | |